


Motorcycle Manufacturer	 HONDA
Model	VFR 800
Issue	11/99 – rev. 01

Recommended siting	On the right side of the rear frame, behind the fuel pump relay.
Power supply	Connect the positive and the negative supply wires of the alarm system directly to the battery terminals.
Engine immobilisation (1)	Follow Diagram B. Cut the BLACK wire of the fuel pump relay on the right side of the battery.
Engine immobilisation (2)	Follow Diagram B. Cut the YELLOW/RED wire found in the red 4-way connector of the starter solenoid.
Ignition controlled positive supply	Connect to the BLACK/BROWN wire available in the bullet connector or 3-way white connector found behind the right fairing on the harness of the rear stop light switch.
Turn indicators	Connect to the ORANGE wire and LIGHT BLUE wire of the rear turn indicators.