


Motorcycle Manufacturer	 HONDA
Model	VT 750 SHADOW
Year	//
Issue	04/99 – rev. 00

Recommended siting	Under the right fairing.
Power supply	Connect the positive and the negative supply wires of the alarm system directly to the battery terminals.
Engine immobilisation (1)	Follow diagram B. Cut the BLACK/WHITE wire available in the connector of the electronic control unit, placed under the front seat, over the battery.
Engine immobilisation (2)	Cut the YELLOW/RED wire available in the red 4-way connector on the starter solenoid, found on the left of the battery.
Ignition controlled positive supply	Connect to the RED/BLACK wire available in the black 3-way connector that is secured to the connector-holder behind the fuse-box, behind the right fairing.
Turn indicators	Connect to the ORANGE wire and LIGHT BLUE wire that are available inside the rubber protection boot behind the right fairing.