



Motorcycle Manufacturer	<i>italjet</i> <i>m o t o</i>
Model	FORMULA 50 and 125
Issue	4/98 – rev. 00

Recommended siting

Behind the front shield.

Power supply

Connect the positive supply wire of the alarm system to the RED/BLACK wire and the negative supply wire to the BLACK wire of the ignition lock.

Engine immobilisation (1)

Follow diagram A. Connect to the WHITE/RED wire available in the single connector of the harness that comes out of the ignition lock..

Engine immobilisation (2)

Follow diagram B. Cut the YELLOW/RED wire available in the 6-way white connector behind the front shield.

Ignition controlled positive supply

Connect to the WHITE/RED wire available in the 4-way connector of the harness that comes out of the ignition lock.

Turn indicators

Connect to the LIGHT BLUE and RED wires available in the 9-way connector behind the front shield.