



Motorcycle Manufacturer	<i>italjet</i> m o t o
Model	TORPEDO (all capacities)
Year	//
Issue	04/00

Recommended siting	Behind the front shield.
Power supply	Connect the positive supply wire of the alarm system to the ORANGE wire and the negative supply wire of the alarm system to the BLUE wire. These wires are available in the 5-way connector, on the wiring loom coming out of the ignition lock.
Engine immobilisation (1)	Follow Diagram A. Connect to the WHITE/BLACK wire available in the one-way connector, on the wiring loom coming out of the ignition lock.
Engine immobilisation (2)	Cut the YELLOW/RED wire available in the loom coming down from the handlebar.
Ignition controlled positive supply	Connect to the GREEN/RED wire available in the 5-way connector, on the loom coming out of the ignition lock.
Turn indicators	Connect to the LIGHT BLUE wire and to the RED wire available directly on the front turn indicators.