



<b>Motorcycle Manufacturer</b>	<b>Kawasaki</b>
<b>Model</b>	<b>VN 1600</b>
<b>Issue</b>	<b>03/04 Rev. 00</b>

<b>Recommended siting</b>	Secure the alarm unit inside the compartment that is available behind the right fairing, under the coolant bottle.
<b>Power supply</b>	Connect the positive supply wire and the negative supply wire of the alarm system directly to the positive and negative terminals of the bike's battery.
<b>Engine immobilisation (1)</b>	Cut the RED/GREEN wire available in the 9-way green connector under the right side of the fuel tank.
<b>Engine immobilisation (2)</b>	Cut the RED/BLACK wire available in the 9-way green connector under the right side of the fuel tank.
<b>Ignition controlled positive supply</b>	Connect to the RED/BLUE wire available in the 9-way green connector under the right side of the fuel tank.
<b>Turn indicators</b>	Connect to the GREEN and GREY wires available in the 6-way white connector of the harness that powers the tail light, under the seat on the left.