



Motorcycle Manufacturer	KYMCO
Model	B & W
Issue	10/00 Rev. 00

Recommended siting	Fix the alarm case on the plastic wall over the radiator, between the two head-lamps.
Power supply	Connect the positive supply wire of the alarm system to the RED wire and the negative supply wire of the alarm system to the GREEN wire both available in the 6-way connector of the wiring loom coming out of the ignition lock.
Engine immobilisation (1)	Follow diagram A. Connect to the BLACK/WHITE wire available in the 6-way connector of the loom coming out of the ignition lock.
Engine immobilisation (2)	Cut the YELLOW/RED wire available in the 6-way connector of the loom coming down from the handle-bar, on the right of the steering post.
Ignition controlled positive supply	Connect to the BLACK wire available in the 6-way connector of the loom coming out of the ignition lock.
Turn indicators	Connect to the LIGHT BLUE wire and to the ORANGE wire of the front turn indicators.