



Motorcycle Manufacturer	KYMCO
Model	DINK, HEROISM, PEOPLE and FILLY
Year	//
Issue	10/99 – rev. 01

Recommended siting	Install the alarm system behind the front shield.
Power supply	Locate the 6-way connector on the wiring loom coming out of the ignition lock. Connect the positive supply wire of the alarm system to the RED wire and the negative supply wire of the alarm system to the GREEN wire of the connector.
Engine immobilisation (1)	Follow diagram A. Connect to the BLACK/WHITE wire available in the 6-way connector of the loom coming out of the ignition lock.
Engine immobilisation (2)	Cut the YELLOW/RED wire available in the 9-way connector on the right of the steering post.
Ignition controlled positive supply	Connect to the BLACK wire available in the 6-way connector of the loom coming out of the ignition lock.
Turn indicators	Connect to the LIGHT BLUE wire and ORANGE wire available on the front turn indicators.