


Motorcycle Manufacturer	MBK 
Model	SKYLINER
Year	1998
Issue	10/98 – rev. 00

Recommended siting	Under the front shield.
Power supply	Connect the positive supply wire of the alarm system to the RED wire and the negative supply wire of the alarm system to the BLACK wire of the white 3-way connector available near the steering post, on the left of the ignition lock.
Engine immobilisation (1)	Follow diagram A. Connect to the WHITE/BLACK wire available in the single connector that comes out of the the ignition lock.
Engine immobilisation (2)	Cut the LIGHT BLUE/WHITE bridge of the white 2-way connector available near the steering post, on the left of the ignition lock.
Ignition controlled positive supply	Connect to the BROWN wire of the white 3-way connector available near the steering post, on the left of the ignition lock.
Turn indicators	Connect to the GREEN wire and BROWN wire of the black 2-way connector available near the steering post, on the left of the ignition lock.