


<b>Motorcycle Manufacturer</b>	<b>MBK</b> 
<b>Model</b>	<b>TARGET</b>
<b>Issue</b>	<b>06/98</b>

<b>Recommended siting</b>	Behind the front shield.
<b>Power supply</b>	Connect the positive supply wire of the alarm system to the ORANGE wire and the negative supply wire to the BLUE wire both found in the 4-way white connector of the harness that comes out of the ignition lock.
<b>Engine immobilisation (1)</b>	Follow diagram A. Connect to the BLACK/WHITE wire available in the single connector of the harness that comes out of the ignition lock.
<b>Engine immobilisation (2)</b>	Follow diagram B. Cut the BLUE/WHITE wire available in the harness that comes down from the handle-bar, close to the steering post.
<b>Ignition controlled positive supply</b>	Connect to the BROWN wire available in the 4-way white connector of the harness that comes out of the ignition lock.
<b>Turn indicators</b>	Connect to the DARK GREEN and DARK BROWN wires of the front turn indicators.