


Motorcycle Manufacturer	 PEUGEOT
Model	GEO 50 and RAPIDO ST 50 L
Issue	3/97 – rev. 00

Recommended siting	Behind the front shield.
Power supply	Connect the positive supply wire of the alarm system to the RED wire and the negative supply wire to the GREEN wire of the ignition lock.
Engine immobilisation (1)	Follow diagram A. Connect to the WHITE/BLACK wire available in the harness that comes out of the ignition lock.
Engine immobilisation (2)	Cut the VIOLET wire available in the harness that comes out of the handle-bar, close to the steering post.
Ignition controlled positive supply	Connect to the BLACK wire of the harness that comes out of the ignition lock.
Turn indicators	Connect to the ORANGE wire (WHITE wire for RAPIDO ST 50 L) and LIGHT BLUE wire of the front turn indicators.