


Motorcycle Manufacturer	 PEUGEOT
Model	SATELLIS 250 cc
Issue	05/07

Recommended siting	Install the alarm system behind the front shield.
Power supply	Connect the positive supply wire of the alarm system to the RED wire available in the harness that comes out of the ignition lock. Connect the negative supply wire of the alarm system to the GREEN wire available in the white 4-way plug that is connected to the front right headlight.
Engine immobilisation (1)	Follow diagram B. Connect to the RED/BLACK wire available in the harness that comes out of the ignition lock.
Ignition controlled positive supply	Connect to the RED/BLACK wire available in the harness that comes out of the ignition lock (same wire as engine immobilisation 1).
Turn indicators	Connect to the ORANGE wire available in the white 6-way connector of the front left headlamp and to the LIGHT BLUE wire available in the white 4-way connector of the front right headlamp.