


Motorcycle Manufacturer	 PEUGEOT
Model	SPEEDFIGHT 50 / 100cc and TREKKER 50 / 100 cc
Issue	10/99 – rev. 01

Recommended siting	Install the alarm system behind the front shield.
Power supply	<p>Connect the positive supply wire of the alarm system to the RED wire available in the wiring loom that comes out of the ignition lock.</p> <p>Connect the negative supply wire of the alarm system to the GREEN wire available in the white 12-way connector placed behind the front shield.</p>
Engine immobilisation (1)	Follow diagram A. Connect to the RED/BLACK wire available in the loom coming out of the ignition lock.
Engine immobilisation (2)	Cut the GREEN wire available in the white 6-way connector placed behind the front shield.
Ignition controlled positive supply	Connect to the BLACK wire available in the loom coming out of the ignition lock.
Turn indicators	Connect to the ORANGE wire and to the LIGHT BLUE wire available in the white 12-way connector placed behind the front shield.