


Motorcycle Manufacturer	 PEUGEOT
Model	SQUAB
Issue	4/98 – rev. 00

Recommended siting	Behind the front shield, under the ignition lock.
Power supply	Connect the positive supply wire of the alarm system to the RED wire and the negative supply wire to the GREEN wire available in the harness that comes out of the ignition lock.
Engine immobilisation (1)	Follow diagram A. Connect to the RED/BLACK wire available in the harness that comes out of the ignition lock.
Engine immobilisation (2)	Follow diagram B. Cut the VIOLET wire of the 6-way white connector behind the front shield.
Ignition controlled positive supply	Connect to the BLACK wire available in the harness that comes out of the ignition lock.
Turn indicators	Connect to the ORANGE and LIGHT BLUE wires placed in the 9-way white connector under the ignition lock.