


<b>Motorcycle Manufacturer</b>	 <b>PEUGEOT</b>
<b>Model</b>	<b>VIVACITY 50cc</b>
<b>Issue</b>	<b>10/99 – rev. 00</b>

<b>Recommended siting</b>	Install the alarm system behind the lower part of the front shield.
<b>Power supply</b>	Connect the positive supply wire of the alarm system to the RED wire and the negative supply wire of the alarm system to the GREEN wire available in the wiring loom that comes out of the ignition lock.
<b>Engine immobilisation (1)</b>	Follow diagram A. Connect to the RED/BLACK wire available in the loom coming out of the ignition lock.
<b>Engine immobilisation (2)</b>	Cut the GREEN wire available in the white 6-way connector behind the front shield.
<b>Ignition controlled positive supply</b>	Connect to the BLACK wire available in the loom coming out of the ignition lock.
<b>Turn indicators</b>	Connect to the ORANGE wire and LIGHT BLUE wire of the front turn indicators.