


Motorcycle Manufacturer	 PIAGGIO
Model	CARNABY 125-200 ES
Issue	05/07 Rev. 00

Recommended siting	Under the front shield.
Power supply	Connect the positive supply wire of the alarm unit to the RED/BLACK wire found in the white 4-way plug that is connected to the ignition lock. Connect the negative supply wire of the alarm unit to the BLACK wire that is connected to the right turn indicator.
Engine immobilisation (1)	Follow diagram B. Cut the ORANGE wire found in the 4-way white plug that is connected to the ignition lock.
Engine immobilisation (2)	Cut the GREEN/BLACK wire that comes out of the start button, on the right switch.
Ignition controlled positive supply	Connect to the ORANGE wire available in the 4-way white plug that is connected to the ignition lock (same wire as engine immobiliser 1).
Turn indicators	Connect to the PINK and BLUE/WHITE wires of the front turn indicators.