


Motorcycle Manufacturer	 PIAGGIO
Model	FREE 50, QUARTZ 50, SFERA 50 and ZIP 50
Issue	3/98 – rev. 00

Recommended siting	Behind the front shield.
Power supply	Connect the positive supply wire of the alarm system to the RED wire and the negative supply wire to the BLACK wire of the ignition lock.
Engine immobilisation (1)	Follow diagram A. Connect to the GREEN wire available in the connector of the harness that comes out of the ignition lock.
Engine immobilisation (2)	Cut the GREEN/BLACK wire available in the harness that comes down from the handle-bar, close to the steering post.
Ignition controlled positive supply	Connect to the WHITE wire available in the connector of the harness that comes out of the ignition lock.
Turn indicators	Connect to the PINK and WHITE wires of the front turn indicators.