


Motorcycle Manufacturer	 SUZUKI
Model	AP 50
Issue	7/98 Rev. 00

Recommended siting

Under the front shield.

Power supply

Connect the positive supply wire of the alarm system to the RED wire of the connector in the harness of the ignition lock and the negative supply wire to the WHITE/BLACK wire of the 6-way connector of the head lamp.

Engine immobilisation (1)

Follow diagram A. Connect to the BLACK/RED wire available in the single terminal that comes out of the ignition lock.

Engine immobilisation (2)

Follow diagram B. Cut the YELLOW/GREEN wire available inside the sleeve that comes down from the handlebar.

Ignition controlled positive supply

Connect to the ORANGE wire of the connector of the ignition lock harness.

Turn indicators

Connect to the LIGHT GREEN and BLACK wires of the 6-way connector of the headlamp.