


Motorcycle Manufacturer	 SUZUKI
Model	BANDIT 600 – 1200 ym 2003
Issue	04/03 Rev. 00

Recommended siting	Install the alarm system under the rear right fairing.
Power supply	<p>Connect the positive power supply wire of the security system to the BLACK wire found in the white single connector that is located under the tail fairing, behind the tail light.</p> <p>Connect the negative power supply wire of the security system to the BLACK wire found in pos. 2 of the white 4-way connector that is also located under the tail fairing, behind the tail light.</p>
Engine immobilisation (1)	Follow diagram B. Cut the BLACK wire bridge of the white 4-way connector that is sited under the fairing of the tail light, behind the tail lamp.
Engine immobilisation (2)	Cut the YELLOW/GREEN wire available in the connector of the starter solenoid, behind the battery.
Ignition controlled positive supply	Connect to the BLACK wire in pos. n. 4 of the white 4-way connector that is sited under the tail fairing, behind the tail lamp.
Turn indicators	Connect to the BLACK and LIGHT GREEN wires available in the 2-way connectors of the rear turn indicators, under the tail fairing.