


Motorcycle Manufacturer	 SUZUKI
Model	BURGMAN
Issue	10/98 – rev. 00

Recommended siting	Under the front shield.
Power supply	Connect the positive supply wire of the alarm system to the RED wire of the black 6-way connector available under the instruments, on the left. Connect the negative supply wire of the alarm system to the BLACK/WHITE wire of the yellow 13-way connector available under the instruments, on the right.
Engine immobilisation (1)	Cut the ORANGE/WHITE wire of the black 10-way connector available under the instruments, on the right.
Engine immobilisation (2)	Cut the YELLOW/GREEN wire of the black 10-way connector placed under the instruments, on the right.
Ignition controlled positive supply	Connect to the BLACK/RED wire of the black 10-way connector found under the instruments, on the right.
Turn indicators	Connect to the BLACK wire and to the LIGHT GREEN wire of the yellow 13-way connector available under the instruments, on the right.