


Motorcycle Manufacturer	 SUZUKI
Model	BURGMAN BUSINESS
Issue	10/01 Rev. 00

Recommended siting	Under the front shield.
Power supply	Connect the positive supply wire of the alarm system to the RED wire of the black 6-way connector found under the instruments on the left. Connect the negative supply wire of the alarm system to the BLACK/WHITE wire of the 13-way yellow connector available under the instruments on the right.
Engine immobilisation (1)	Follow diagram B. Cut the ORANGE/WHITE wire of the 10-way black connector found under the instruments on the right side.
Engine immobilisation (2)	Cut the YELLOW/GREEN wire of the 10-way black connector found under the instruments on the right.
Ignition controlled positive supply	Connect to the BLACK/RED wire of the 10-way black connector available under the instruments on the right.
Turn indicators	Connect to the BLACK and LIGHT GREEN wires of the 13-way yellow connector available under the instruments on the right.

Remark: to avoid backfeeds through the turn indicators, it is recommended to fit a diode to the ORANGE/GREEN wire connected to the flasher unit. The latter is secured to the fuse-box on the right of the headlamp, under the front fairing, behind the front left turn indicator.

