


Motorcycle Manufacturer	 SUZUKI
Model	FREEWIND 650
Issue	06/99 Rev. 00

Recommended siting	Behind the left fairing, under the starter solenoid.
Power supply	Connect the positive and the negative supply wires directly to the battery terminals.
Engine immobilisation (1)	Follow diagram B. Cut the ORANGE wire available in the 4-way connector on the relay available behind the right fairing, behind the regulator.
Ignition controlled positive supply	Connect to the ORANGE/WHITE wire available in the white 2-way connector of the micro-switch of the stop light, on the starter solenoid.
Turn indicators	Connect to the BLACK wire and LIGHT GREEN wire available on the rear turn indicators.