


Motorcycle Manufacturer	 SUZUKI
Model	SV 650 / 1000 and GSX-R 1000 ym 2003
Issue	04/03 Rev. 00

Recommended siting	Secure the alarm unit to the rear right frame, under the tail fairing.
Power supply	<p>Connect the positive supply wire of the alarm system to the BLACK wire available in the single white connector that is taped to the harness powering the tail light, under the left tail fairing.</p> <p>Connect the negative supply wire of the alarm system to the BLACK wire available in pos. 2 of the 4-way white connector that is taped to the harness powering the tail light, under the left tail fairing.</p>
Engine immobilisation (1)	Follow diagram B. Cut the BLACK jumper wire of the 4-way white connector that is taped to the harness powering the tail light, under the left tail fairing.
Engine immobilisation (2)	Cut the YELLOW/GREEN wire available in the connector that is attached to the starter solenoid, behind the battery.
Ignition controlled positive supply	Connect to the BLACK wire available in the 4-way white connector that is taped to the harness powering the tail light, under the left tail fairing.
Turn indicators	Connect to the BLACK and LIGHT GREEN wires found in the 2-way connectors that are attached to the rear turn indicators, under the left tail fairing.