


Motorcycle Manufacturer	 SUZUKI
Model	SV 650
Issue	06/99

Recommended siting	Behind the left fairing.
Power supply	Connect the positive and the negative supply wires of the alarm system directly to the battery terminals.
Engine immobilisation (1)	Follow diagram B. Cut the LIGHT BLUE/WHITE wire available in the 2-way connector found behind the right fairing, on the right of the battery.
Engine immobilisation (2)	Cut the YELLOW/BLACK wire available in the connector of the starter solenoid, in front of the battery.
Ignition controlled positive supply	Connect to the ORANGE/GREEN wire available in the white 2-way connector of the micro-switch of the stop light, behind the right fairing, on the right of the battery.
Turn indicators	Connect to the BLACK wire and LIGHT GREEN wire available in the loom placed under the seat, behind the left fairing.