


<b>Motorcycle Manufacturer</b>	 <b>YAMAHA</b>
<b>Model</b>	<b>NEOS</b>
<b>Issue</b>	<b>01/99 – rev. 00</b>

<b>Recommended siting</b>	Under the front shield, on the left.
<b>Power supply</b>	Connect the positive supply wire of the alarm system to the RED wire and the negative supply wire of the alarm system to the BLACK wire of the 4-way connector coming out of the ignition lock.
<b>Engine immobilisation (1)</b>	Diagram A. Connect to the BLACK/WHITE wire of the single connector coming out of the ignition lock.
<b>Engine immobilisation (2)</b>	Cut the LIGHT BLUE/WHITE wire available in the loom coming down from the handle-bar, close to the steering post.
<b>Ignition controlled positive supply</b>	Connect to the BROWN wire of the 4-way connector coming out of the ignition lock.
<b>Turn indicators</b>	Connect to the GREEN wire and to the BROWN wire of the front turn indicators.