


Motorcycle Manufacturer	 YAMAHA
Model	VX VIRAGO
Issue	08/01 – rev. 00

Recommended siting	Install the alarm system in the tool compartment under the rear seat. Cut the fixing wings of the plastic case and make a hole in the wall of the tool compartment to allow the exit of the wiring loom.
Power supply	Connect the positive and the negative supply wires of the alarm system directly to the battery terminals.
Engine immobilisation (1)	Follow diagram B. Cut the GREY wire available in the white 2-way connector, placed behind the left side fairing (pick-up).
Engine immobilisation (2)	Cut the BLUE/WHITE wire available in the white 2-way connector, placed behind the left side fairing (starter solenoid).
Ignition controlled positive supply	Connect to the BROWN wire available in the white 4-way connector, on the loom coming out of the ignition lock.
Turn indicators	Connect to the GREEN wire and to the BROWN wire available under the front seat, in front of the tool compartment.