


Motorcycle Manufacturer	 YAMAHA
Model	XJ 600 N
Issue	06/99 – rev. 00

Recommended siting	Install the alarm system behind the left fairing.
Power supply	Connect the positive supply wire of the alarm system to the RED wire coming out of the 30A fuse, placed in the fuse-box, behind the battery. Connect the negative supply wire of the alarm system directly to the battery terminal.
Engine immobilisation (1)	Follow diagram B. Cut the RED/WHITE wire (\varnothing 0,75) connected to the 10A fuse placed in the fuse-box, behind the battery.
Engine immobilisation (2)	Cut the BLUE/WHITE wire with bullet connectors that is attached to the starter solenoid on the right of the battery.
Ignition controlled positive supply	Connect to the HAZEL BROWN / LIGHT BLUE wire connected to the 15A fuse placed in the fuse-box, behind the battery.
Turn indicators	Connect to the DARK GREEN wire and BROWN wire available in the white 6-way connector placed over the rear fender, under the seat, on the right.