



<b>Motorcycle Manufacturer</b>	<b>aprilia</b>
<b>Model</b>	<b>PEGASO '98</b>
<b>Year</b>	<b>//</b>
<b>Issue</b>	<b>05/99 – rev. 00</b>

<b>Recommended siting</b>	Under the carrier, in the tool compartment.
<b>Power supply</b>	Connect the positive and the negative supply wires of the alarm system directly to the battery.
<b>Engine immobilisation (1)</b>	Follow diagram B. Cut the RED/GREY wire available in the 6-way connector placed on the wiring loom coming out of the electronic control unit, under the seat.
<b>Engine immobilisation (2)</b>	Cut the YELLOW/RED wire available in the 6-way connector placed on the connector-holder, first connector on the right, under the water temperature indicator.
<b>Ignition controlled positive supply</b>	Connect to the GREEN/ORANGE wire available in the connector on the loom coming out of the ignition lock.
<b>Turn indicators</b>	Connect to the LIGHT BLUE wire and RED wire available in the white 6-way connector found behind the left fairing, on the right of the battery.