



<b>Motorcycle Manufacturer</b>	<b>aprilia</b>
<b>Model</b>	<b>SR 125</b>
<b>Year</b>	<b>//</b>
<b>Issue</b>	<b>09/99 – rev. 00</b>

<b>Recommended siting</b>	Behind the front shield, on the right of the steering post.
<b>Power supply</b>	Connect the positive supply wire of the alarm system to the ORANGE wire and the negative supply wire of the alarm system to the BLUE wire. These wires are available in the white 4-way connector of the loom coming out of the ignition lock.
<b>Engine immobilisation (1)</b>	Follow Diagram A. Connect to the WHITE/BLACK wire available in the white one-way connector of the loom coming out of the ignition lock.
<b>Engine immobilisation (2)</b>	Cut the YELLOW/RED wire on the relay of the starter, found in front of the left footrest.
<b>Ignition controlled positive supply</b>	Connect to the GREEN wire available in the white 4-way connector of the loom coming out of the ignition lock.
<b>Turn indicators</b>	Connect to the LIGHT BLUE wire and RED wire available on the front turn indicators.