


Motorcycle Manufacturer	 HONDA
Model	SJ 50 BALI
Issue	6/98 – rev. 00

Recommended siting	Under the front shield.
Power supply	Connect the positive supply wire of the alarm system to the RED wire of the 6-way connector that is located inside the rubber protection boot behind the front shield. Connect the negative supply wire to the GREEN wire found in one of the 2-way connectors of the front turn indicators.
Engine immobilisation (1)	Follow diagram A. Connect to the BLACK/WHITE wire found in the 6-way connector that is inside the rubber protection boot behind the front shield.
Engine immobilisation (2)	Follow diagram B. Cut the YELLOW/RED wire found in the 9-way connector that is inside the rubber protection boot behind the front shield.
Ignition controlled positive supply	Connect to the BLACK wire found in the 6-way connector that is inside the rubber protection boot behind the front shield.
Turn indicators	Connect to the ORANGE and LIGHT BLUE wires of the 2-way connectors of the turn indicators.