

Motorcycle Manufacturer	HONDA
Model	VISION 50 SA
Issue	3/98 – rev. 00

Recommended siting Behind the front shield.

Power supplyConnect the positive supply wire of the alarm system

to the RED wire and the negative supply wire to the GREEN wire of the harness that comes out of the

ignition switch.

Engine immobilisation (1) Follow diagram A. Connect to the BLACK/WHITE wire

of the ignition switch.

Ignition controlled positive

supply

Connect to the BLACK wire of the in the harness that

comes out of the ignition switch.

Turn indicators Connect to the ORANGE and LIGHT BLUE wires of

the front turn indicators.