



Motorcycle Manufacturer	<i>italjet</i> m o t o
Model	MILLENNIUM
Year	//
Issue	04/00 – rev. 00

Recommended siting	Behind the front shield.
Power supply	Connect the positive supply wire of the alarm system to the RED wire and the negative supply wire of the alarm system to the GREEN wire. These wires are available in the 6-way connector on the loom coming out of the ignition lock.
Engine immobilisation (1)	Follow Diagram A. Connect to the BLACK/WHITE wire in the 6-way connector on the on the loom coming out of the ignition lock.
Engine immobilisation (2)	Connect to the YELLOW/RED wire in the 9-way connector on the right of the steering post.
Ignition controlled positive supply	Connect to the BLACK wire available in the 6-way connector on the wiring loom coming out of the ignition lock.
Turn indicators	Connect to the LIGHT BLUE and ORANGE wire available directly on the front turn indicators.