



Motorcycle Manufacturer	Kawasaki
Model	ZX12-R
Issue	06/00 – rev. 00

Recommended siting	Behind the right fairing, under the seat.
Power supply	Connect the positive and the negative supply wires of the alarm system directly to the positive and the negative terminals of the battery.
Engine immobilisation (1)	Follow Diagram B. Cut the RED wire available in the brown 4-way connector on the fuel pump relay. This relay is placed under the plastic cover of the fuel tank, on the front side.
Engine immobilisation (2)	Cut the YELLOW/RED wire available in the white 8-way connector found behind the metal cover, inside the battery compartment.
Ignition controlled positive supply	Connect to the RED/WHITE wire available in the white 2-way connector of the rear stop light switch, under the fuel tank.
Turn indicators	Connect to the GREEN wire and to the GREY wire available in the black and in the grey 2-way connectors, placed on the right of the glove compartment under the seat.