



Motorcycle Manufacturer	Kawasaki
Model	ZZR 600
Issue	7/95 – rev. 00

Recommended siting	In the rear tail behind the lamp.
Power supply	Connect the positive and the negative supply wires of the alarm system to the motorcycle battery.
Engine immobilisation (1)	Follow diagram B. Cut the YELLOW wire of the ignition unit placed on the right side of the battery.
Engine immobilisation (2)	Follow diagram B. Cut the YELLOW/RED wire of the starter solenoid.
Ignition controlled positive supply	Connect to the BROWN wire of the fuse-box under the seat.
Turn indicators	Connect to the GREEN and GREY wires of the rear turn indicators.