

Motorcycle Manufacturer	<i>Malaguti</i>
Model	Centro 160 cc.
Issue	09/07 Rev. 00

Recommended siting	Secure the alarm unit over the plastic panel above the ignition lock, under the front shield.
Power supply	Connect the positive supply wire of the alarm system to the BLUE/RED wire available in the 6-way white plug that is connected to the harness exiting the ignition lock, under the front shield on the right. Connect the negative supply wire of the alarm system to the BLACK wire available in the free 3-way white connector that is also located under the front shield on the right side.
Engine immobilisation (1)	Follow diagram B. Cut the BLUE wire available in the 6-way white plug that is connected to the harness exiting the ignition lock under the front shield on the right side.
Engine immobilisation (2)	Cut the WHITE/RED wire found in the white 6-way plug that is connected to the harness exiting the right switch under the instrument panel on the right side.
Ignition controlled positive supply	Connect to the BLUE wire available in the white 6-way plug that is connected to the harness exiting the ignition lock under the front shield on the right side. Same wire as engine immobilisation (1).
Turn indicators	Connect to the GREEN and VIOLET wires available in the free white 3-way connector that is located under the front shield on the right side.