


Motorcycle Manufacturer	 SUZUKI
Model	EPICURO
Issue	05/99

Recommended siting	Behind the rear left fairing, near the shock-absorber support.
Power supply	Connect the positive supply wire of the alarm system to the RED wire and the negative supply wire of the alarm system to the BLACK/WHITE wire. These wires are available in the white 2-way connector near the frame tube, under the interior light of the tool compartment, under the seat.
Engine immobilisation (1)	Follow diagram B. Cut the ORANGE wire available in the black 4-way connector of the relay that is sited on the right of the interior light of the tool compartment, under the seat.
Ignition controlled positive supply	Connect to the ORANGE wire available in the black 2-way connector found near the frame tube, under the interior light of the tool compartment.
Turn indicators	Connect to the BLACK wire of the white 2-way connector and to the LIGHT GREEN wire available in the black 2-way connector located near the frame tube, under the interior light of the tool compartment, under the seat.