


Motorcycle Manufacturer	 SUZUKI
Model	KATANA 50
Issue	06/99 Rev. 01

Recommended siting	Under the front shield, in front of the ignition lock.
Power supply	Connect the positive supply wire of the alarm system to the RED wire and the negative supply wire of the alarm system to the BLACK/WHITE wire available in the green 9-way connector coming out of the ignition lock.
Engine immobilisation (1)	Follow diagram A. Connect to the RED/BLACK wire with a bullet terminal that comes out of the ignition lock.
Engine immobilisation (2)	Cut the YELLOW/GREEN wire available in the wiring loom that comes down from the handle-bar.
Ignition controlled positive supply	Connect to the ORANGE wire available in the green 9-way connector that comes out of the ignition lock.
Turn indicators	Connect to the GREEN wire and BLACK wire available in the loom that comes down from the handle-bar.