



Motorcycle Manufacturer	SYM
Model	SHARK
Issue	02/00 – rev. 00

Recommended siting	Behind the front shield.
Power supply	Locate the white 4-way connector at the exit of the ignition lock: connect the positive supply wire of the alarm system to the RED wire and the negative supply wire of the alarm system to the GREEN wire.
Engine immobilisation (1)	Follow diagram A. Connect to the BLACK/WHITE wire available in the white 4-way connector at the exit of the ignition lock.
Engine immobilisation (2)	Cut the YELLOW/RED wire in the red 4-way connector placed behind the front shield.
Ignition controlled positive supply	Connect to the BLACK wire in the white 4-way connector at the exit of the ignition lock.
Turn indicators	Connect to the GREY wire and to the ORANGE wire available in the red 4-way connector, behind the front shield.