

Motorcycle Manufacturer	YAMAHA
Model	AEROX 50
Issue	06/99 – rev. 00

**Recommended siting** Under the front shield.

**Power supply**Connect the positive supply wire of the alarm system

to the RED wire and the negative supply wire to the BLACK wire of the 4-way connector of the key switch

placed under the front shield.

**Engine immobilisation (1)** Follow diagram A. Connect to the BLACK/WHITE wire

with a bullet connector of the ignition lock placed

under the front shield.

**Engine immobilisation (2)** Follow diagram B. Cut the LIGHT BLUE/WHITE wire

of the 6-way connector of the right switch placed

under the instruments.

Ignition controlled positive

supply

Connect to the BLACK wire in the 4-way connector of

the ignition lock under the front shield.

Turn indicators Connect to the GREEN and BROWN wires of the front

turn indicators.