


Motorcycle Manufacturer	 YAMAHA
Model	FZX 750
Issue	7/95 – rev. 00

Recommended siting	Under the seat near the battery, via the bracket that holds the fuse support.
Power supply	Connect the positive and the negative supply wires of the alarm system to the battery terminals.
Engine immobilisation (1)	Follow diagram B. Cut the BLACK/RED wire of the connector of the ignition lock, behind the steering post.
Engine immobilisation (2)	Follow diagram B. Cut the LIGHT BLUE/WHITE wire of the connector of the right switch located behind the steering post.
Ignition controlled positive supply	Connect to the BROWN wire of the connector of the ignition lock located behind the steering post.
Turn indicators	Connect to the DARK GREEN and BROWN wires of the rear turn indicators.