


Motorcycle Manufacturer	 YAMAHA
Model	YZF 750
Issue	7/95 – rev. 00

Recommended siting	On the front right side, via the upper screw that holds the radiator.
Power supply	Connect the positive supply wire of the alarm system to the RED wire of the 4-way connector of the ignition lock. Connect the negative supply wire to the BLACK wire of the 9-way connector of the left switch.
Engine immobilisation (1)	Follow diagram B. Cut the RED/BLACK wire of the connector of the right switch located behind the steering post, under the fuel tank.
Engine immobilisation (2)	Follow diagram B. Cut the LIGHT BLUE wire of the connector of the right switch located behind the steering post, under the fuel tank.
Ignition controlled positive supply	Connect to the BROWN wire of the 4-way connector of the ignition lock.
Turn indicators	Connect to the DARK GREEN and BROWN wires of the 9-way connector of the left switch.