


<b>Motorcycle Manufacturer</b>	 <b>HONDA</b>
<b>Model</b>	<b>CBR 600</b>
<b>Issue</b>	<b>11/96 – rev. 00</b>

<b>Recommended siting</b>	In the compartment over the fender, behind the tail light.
<b>Power supply</b>	Connect the positive and the negative supply wires of the alarm system to the battery.
<b>Engine immobilisation (1)</b>	Follow diagram B. Cut the BLACK/WHITE wire found in the connector of the CDI, behind the right rear fairing.
<b>Engine immobilisation (2)</b>	Follow diagram B. Cut the YELLOW/RED wire found in the red 4-way connector of the starter solenoid.
<b>Ignition controlled positive supply</b>	Connect to the BLACK/ORANGE wire of the 2-way connector of the rear stop light switch.
<b>Turn indicators</b>	Connect to the ORANGE and LIGHT BLUE wires of the rear turn indicators.