

<b>Motorcycle Manufacturer</b>	
<b>Model</b>	<b>TIGER</b>
<b>Issue</b>	<b>05/02 Rev. 00</b>

<b>Recommended siting</b>	Under the tail fairing, close to the tail light.
<p><i>The bike is pre-equipped with a plug for the connection of a security system, under the tail fairing close to the tail light. Unplug the 12-way female connector housing with male terminals that bears two jumper wires and connect as follows:</i></p>	
<b>Power supply</b>	Connect the RED wire of the loom to the wire in pos. 6 and the BLACK wire of the loom to the wire in pos.12 of the 12-way connector.
<b>Engine immobilisation (1)</b>	Connect the BROWN wire of the loom to the wire in pos. 1 and the VIOLET wire of the loom to the wire in pos. 2 of the 12-way connector
<b>Engine immobilisation (2)</b>	Connect the WHITE/GREEN wire of the loom to the wire in pos. 3 and the other WHITE/GREEN wire of the loom to the wire in pos. 5 of the 12-way connector.
<b>Ignition controlled positive supply</b>	Connect the ORANGE wire of the loom to the wire in pos. 4 of the 12-way connector.
<b>Turn indicators</b>	Connect one one of the YELLOW wires of the loom to the wire in pos. 7. Connect the other YELLOW wire of the loom to the wire in pos. 8 of the 12-way connector.
<p><b>LED connection:</b></p> <ul style="list-style-type: none"> <li>• Connect the BROWN/WHITE wire of the loom to the wire in pos. 10 of the 12-way connector, then make a jumper connection between pos.11 and pos. 6 of the 12-way connector.</li> <li>• Connect the BLACK or BROWN wire of the LED to the GREY wire in pos. 1 and the RED wire of the LED to the ORANGE wire in pos. 2 of the black 2-way free connector that is located under the instruments (pre-wiring).</li> </ul>	